W E I C O N

Technical Datasheet Create Date: 17.11.2017 - Seite 1/1

WEICONLOCK® AN 306-20 Retaining Cylindrical Assemblies



higher viscosity high strength hard to disassemble

TZW

Retaining cylindrical assemblies, high temperature resistant, DVGW-approval, KTW-approved, marking-free



Technical Data

Colour	green
For threaded joints up to	M 56 R 2"
Viscosity at +25°C (+77°F) according to Brookfield	3.000 - 6.000 nt mPa⋅s
Max. gap bridging	0,2 mm
Breakaway strength (Thread)	28 - 36 Nm
Prevailing stregth	40 - 55 Nm
Shear strength Nmm² (DIN 54452)	15 - 25 N/mm²
Handling strength at room temperature	20 - 40 min.
Final strength (100%) after	24 h
Temperature resistance	-60 to +200 °C

*Strength values based on M 10 screws, 8.8 grade, thickness of nut 0,8.d Static shear strength based on cylindrical parts of abt. Ø 13 mm, tolerance (D-d) = 0,05 mm, I/d = 0,88

Surface pre-treatment

In general, WEICONLOCK does not require special pretreatment as slightly oily surfaces (e.g. on as received parts) will be tolerated. However, best results will be achieved on cleaned, degreased parts (use WEICON Surface Cleaner). If required, the parts should be slightly roughened.

Processing

WEICONLOCK is ready for use and should be applied evenly direct from the bottle/tube with the dispensing tip (avoid direct contact of dispensing tip with metal). On press fitted parts and larger cylindrical assemblies a thin and uniform layer should be applied on both surfaces. Join parts quickly. For sliding seats, turn the parts against each other when joining for an optimal distribution of the adhesive. Joint parts should not be moved until handling strength is reached. Do not pour back into the bottle any WEICONLOCK fluid which had contact with metal; even smallest metal particles will cause the content of the bottle to cure. In series construction, the use of manual or automatic applicators is recommended.

Storage

WEICONLOCK can be stored in the unopened original container for at least 24 months at room temperature. Keep away from heat sources and direct sunlight. The air in the bottle/tube keeps WEICONLOCK liquid.

Safety and health

When using WEICON products, the physical, safety technical, toxicological and ecological data and regulations in our EC safety data sheets (www.weicon.com) must be observed.

Available sizes:

30620020	WEICONLOCK® AN 306-20 Retaining Cylindrical Assemblies 20 ml
30620150	WEICONLOCK® AN 306-20 Retaining
30620200	Cylindrical Assemblies 50 ml WEICONLOCK® AN 306-20 Retaining Cylindrical Assemblies 200 ml
Accessories:	
11202400	Sealant and Adhesive Remover, 400 ml
11207400	Surface Cleaner, 400 ml

11207400	Surface Cleaner, 400 ml
11850200	Hand Protective Foam, 200 ml
30700200	Activator F, 200 ml
30955172	Dosing Tips, Size 1
30955179	Dosing Tips, extra thin

Note

The specifications and recommendations given in this technical data sheet must not be seen as guaranteed product characteristics. They are based on our laboratory tests and on practical experience. Since individual application conditions are beyond our knowledge, control and responsibility, this information is provided without any obligation. We do guarantee the continuously high quality of our products. However, own adequate laboratory and practical tests to find out if the product in question meets the requested properties are recommended. A claim cannot be derived from them. The user bears the only responsibility for non-appropriate or other than specified applications.

WEICON GmbH & Co. KG (Headquarters) Germany phone +49 (0) 251 9322 0 info@weicon.de

WEICON SA (Pty) Ltd South Africa phone +27 (0) 21 709 0088 info@weicon.co.za WEICON Middle East L.L.C. United Arab Emirates phone +971 4 880 25 05 info@weicon.ae

WEICON South East Asia Pte Ltd Singapore phone (+65) 6710 7671 info@weicon.com.sg WEICON Inc. Canada phone +1 877 620 8889 info@weicon.ca www.weicon.ca

WEICON Czech Republic s.r.o. Czech Republic phone +42 (0) 417 533 013 info@weiconcz.cz WEICON Kimya Sanayi Tic. Ltd. Şti Turkey phone +90 (0) 212 465 33 65 info@weicon.com.tr www.weicon.com.tr WEICON Romania SRL Romania phone +40 (0) 3 65 730 763 office@weicon.com

WEICON Ibérica S.L. Spain phone +34 (0) 914 7997 34 info@weicon.es